




OFFICE 85



Function key (Fn)

Instructions:

Q-board is a plug and play keyboard device. However, to enable the € sign to work properly, the software settings should be as follows:

- Choose as model / layout: US-International
- Choose as language: US-International

Depending on the operating system / Windows version, these settings can be adjusted using:

- Start/Settings/Control Panel/Keyboard
- Start/Settings/Control Panel/Regional and Language Options

If 'US-International' is not displayed, you might need to use the 'Add' button to select and add this option.

Special keys/Functions:

€	Alt Gr + 5 (If this does not work properly, you may need to adjust the Keyboard and/or Language Settings, as described above)
File Open	To open a file
Save	To save the current file at the current location
Print	To print the current document or the current selection
Cut	To cut the selection (if nothing is selected: no action)
Copy	To copy the selection (if nothing is selected: no action)
Paste	To paste the copied or cut selection (if nothing is copied or cut: no action)
Change Windows	To change between windows (like Alt-Tab)
Open internet browser	Open the Internet browser
Open Outlook	Open Outlook
Open Windows Explorer	Open the Windows Explorer
Scroll Lock	F10 + Fn
Num Lock	F10 (Num lock led will illuminate): Fn + J = 1, Fn + K = 2, Fn + L = 3 etc.
Symbols	Num Lock + Fn + Alt + code Example: Num Lock + Fn + Alt + 'JL7' = ë (using num lock JL7 = 137)