

ENERGIZER™

Foot Support



Free-floating platform allows for intuitive rocking motion to help promote lower leg movement.





HELPS REDUCE back tension and leg fatigue



INVIGORATING RUBBER SURFACE has diverse massage textures that target pressure points on the soles of your feet



THREE HEIGHT SETTINGS (4", $5\frac{1}{4}$ ", and $6\frac{1}{2}$ ") and up to 25° tilt

SPECIFICATIONS:

ITEM #	DIMENSIONS	COLOR	UNIT	
8068001	17 ¹⁵ /16"W x 13 ¹ /4"D x 5 ¹ /16"H	Charcoal/Blue	EA	